

INSTALLATION INSTRUCTIONS:

1. Hang Pump on Tank (adjust screws as needed to secure pump).
2. Cut Suction Tube off at 42 inches (See FIG 1).
Pull Tube through Hose/Tank Fitting. (Note: tube will not slide if 'pushed'.)
Remove Retainer and Weight from cut-off tube and secure to end of Suction Tube.
3. Put Suction Tube into Tank (weighted end first) and screw Fitting into Tank (See FIG 2).
4. See Pump Installation Manual for additional information.

WARRANTY and SERVICE:

Limited Warranty:

Rola-Chem® warrants the original purchaser that this unit is free from manufacturing defects in material and workmanship from the date of the original purchase for one (1) year. If this unit fails within the one (1) year period, it will be replaced or repaired (Rola Chem® option) at no charge. This warranty does not apply to any product damage caused by improper use or if the product was altered.

Rola-Chem®, under no circumstances, shall be liable for any consequential damages directly or indirectly caused by this unit. Please observe all rules and regulations required by state and local regulations, building codes, health codes, OSHA, etc.

Service or warranty Claims: for assistance in the United States, please call:

Rola-Chem®
5858 Centerville Road
St. Paul, MN 55127
(800)-549-4473 or FAX (651) 653-0989,
Monday thru Friday, 8:00 AM-5:00 PM, Central Time




FIG 1




FIG 2

ROLA-CHEM®

PARTS LIST:

ITEM	PART NUMBER	DESCRIPTION
1	561315	TANK-15 GALLON
2	8021410	SCREW, #10-24 x 13/16
3	550202	FITTING, 3/4 MNPT x 1/4 FNPT (BUSHING)
4	550206	FITTING, 1 1/2 MNPT x 3/4 FNPT (BUSHING)
5	550204	FITTING, 3 MNPT PLUG
6	550207	FITTING, 3" ADAPTOR, MODIFIED
7	8150040	RETAINER CLIP

NOTE: See Pump Manual for hose and hose assembly parts.

